

Configuration of DN-X1700 with MAC Audio/MIDI Setup

- On the MAC, go to **Applications > Utilities > Audio MIDI Setup**
- Select DN-X1700 in “Default Input” column.
- Select DN-X1700 in “Default Output” column.
- Select Format Frequency same as “SystemSetting” in DN-X1700’s Utility settings
- Select 8ch-24bit value in “Format CH”

