

DN-S3700 Hybrid MIDI (Serato Scratch Live)

	DN-S3700 CONTROLS	SCRATCH LIVE FUNCTIONALITY	SHIFT1 [DISC EJECT] +
A	CUE	Jump Temp Cue	Set Temp Cue
B	ECHO/LOOP	Browse Button	-
C	FLANGER	History Button	-
D	FILTER	Prepare Button	-
E	AUTO LOOP SET	Auto Loop Button	-
F	A	Loop In Adjust Button	-
G	B	Loop Out Adjust Button	-
H	EXIT/RELOOP	Reloop Button	-
I	MEMO	Loop Roll Button	-
J	TAP	Tap Tempo	-
K	DUMP	Censor Button	-
L	KEY ADJUST	Key Lock Button	-
M	PARAMETERS SW	Load to deck Button	-
	PARAMETERS KNOB	Scroll Library Knob	-
N	BACK	Tab Focus Button	-
O	REWIND	Rewind	-
P	FORWARD	Fast Forward	-
Q	BEND DOWN [-]	Pitch Down	-
R	BEND UP [+]	Pitch Up	-
S	HOT1	Trigger Cue Point Button A0	-
T	HOT2	Trigger Cue Point Button A1	-
U	HOT3	Trigger Cue Point Button A2	-
V	CLR1	Set Cue Point Button A0	-
W	CLR2	Set Cue Point Button A1	-
X	CLR3	Set Cue Point Button A2	-
Y	EFFECTS KNOB	AutoLoopSelect Knob	-
Z	PLAYLIST	Add To Prepare Button	-
a	DISPLAY	Auto Loop Four Button	-
b	TITLE/ID3	Auto Loop Two Button	-
c	TIME	Auto Loop One Button	-
d	NEXT TRACK	Auto Loop Half Button	-
e	A/B TRIM	Auto Loop Fourth Button	-
f	FLIP	Auto Loop Eighth Button	-
g	DISC EJECT	-	SHIFT Button

